

WIRELESS REMOTE PAIRING



PROCESS TO PAIR YOUR REMOTE

PUT YOUR WINCH INTO FREE-SPOOL AS A PRECAUTION

1. Turn your winch power isolator switch off.
2. Switch on your wireless remote.
(Press power button for 5 – 10 seconds)
3. Hold down both IN and OUT buttons,
LED light will be flashing.
4. Turn your winch power isolator switch on.
(Winch will move briefly)
5. Release IN and OUT buttons.

YOUR REMOTE IS NOW PAIRED

